







KAZALO:

-  BIS-MPC MMX - SOS centrala
-  BIS-NS 2405 - ispravljač 220/24V =
-  BIS-OKA 08 - komunikator
-  BIS-SS 01CR T - sobna svjetiljka s razdjelnikom
-  BIS-TR 01F - tipkalo razriješno
-  BIS-TPR 01F - tipkalo pozivno-razriješno
-  BIS-TP 02F - tipkalo pozivno krevetno
-  BIS-TK 02F - tipkalo krevetno ručno
-  BIS-TP SOS T - tipkalo pozivno SOS

UPUTSTVO ZA INSTALACIJU:

- razvod u standardnim podžbuknim cijevima
- ispravljač se montira nadžbukno u kutiju 190x140x70
- sobna svjetiljka s razdjelnikom i tipkala montiraju se u razvodnu kutiju fi 60 mm
- tipkala se montiraju na visinu prekidača za svjetlo
- tipkalo BIS-TP SOS T se montira na visinu 200 cm
- komunikator OKA montira se u razvodnu kutiju 95 x 95
- na jedan standardni komunikator moguće je spojiti do 8 soba

BIS-SOS ADRESABILNI MPC-MMX - bolnički (domovi umirovljenika)